



UNIVERSAL CLEANER – DEGREASER



EAN code: 5907588404730 item no.: 0014012 cap. 400ml

+ PROPERTIES

The remover is an agent perfectly suitable for removing all greasy stains and dirt from tar, asphalt, synthetic resins from such surfaces as metal, glass, plastics, fabrics, ceramic tiles, etc. Indispensable for household work when degreasing surfaces e. g. before painting or gluing tape.

••• COLOUR

colorless

↷ METHOD OF USE

Shake the container for about 3 minutes before use. Apply the remover to the greasy or soiled surface and then wipe in one direction using a disposable paper towel or clean cloth. If necessary, repeat the operation. After degreasing the surface, the residue of the remover evaporates.

↓ APPLICATION

Mix thoroughly



Apply to greasy or dirty surface



Wipe in one direction with a disposable paper towel or clean cloth

+ PHYSICAL PROPERTIES

physical state: aerosol
density at 20°C: 0,672 g/cm³



STORAGE CONDITIONS



Protect the product from excessive heat and cold. Avoid direct exposure to sunlight. Store in a dry place.



SHELF LIFE

24 months from the date of production placed on the package.



SAFETY

See Safety Data Sheet.



OTHER INFORMATION

All technical data are approximate values. We advise you to test the material to ensure suitability for your specific application. The producer reserves the right to improve the product and change the technical conditions with the possibility of making changes inside the specification.